



**INSTALLATION INSTRUCTIONS FOR ACI
84-96 REAR WINGS
AWF040, AWF060, AWF200, AWF210**

THE FOLLOWING INSTRUCTIONS ARE INTENDED TO FACILITATE THE INSTALLATION OF THE PART NUMBERS LISTED. YOU MAY CALL AMERICAN CUSTOM INDUSTRIES FOR TECHNICAL ADVICE, 8:00AM TO 5:00PM EASTERN, SHOULD YOU NEED ASSISTANCE AT 1-800-822-8020.

1. USING STRIPS OF 2" MASKING TAPE, TAPE OFF THE AREA OF THE BUMPER THAT THE WING WILL SIT ON.
2. CENTER THE WING ON THE BUMPER. **NOTE... CHECK GAS DOOR CLEARANCE!**
3. USING A GREASE PENCIL, TRACE THE FEET OF THE WING ONTO THE MASKING TAPE. FLIP WING UPSIDE DOWN AND TRANSFER MOUNTING HOLE LOCATIONS ON WING FEET TO MASKING TAPE. **TIP... YOU MAY ALSO MAKE A TEMPLATE BY PLACING THE WING ON A PIECE OF PAPER OR CARDBOARD, TRACING THE FOOT AND CUTTING IT OUT, REPLACING IT BACK ONTO THE WING FOOT, AND POKING HOLES THROUGH THE TEMPLATE INTO THE MOUNTING HOLES ON WING.**
4. ONCE THE HOLE LOCATIONS ARE MARKED ON THE CAR, DOUBLE CHECK YOUR MEASUREMENTS, AND USE A 5/16" DRILL BIT TO DRILL THE HOLES.
5. TO GAIN ACCESS FOR INSTALLATION, REMOVE THE REAR LICENSE PLATE. REACH THROUGH THE OPENING AND REMOVE THE BACKUP LIGHTS AND INNER TAIL LAMPS.
6. CHECK THE FIT OF THE WING TO THE CAR. ELONGATING THE HOLES MAY BE NECESSARY TO ACHIEVE PROPER CENTERING AND FIT.
7. ONCE YOU ARE SATISFIED WITH THE FIT, REMOVE THE WING, COMPLETE ANY NECESSARY PREP AND PAINT WORK, AND REINSTALL. **NOTE... DO NOT OVER-TIGHTEN BOLTS. TIP... ACI RECOMMENDS THE USE OF LOCTITE ON ALL BOLT THREADS.**
8. REINSTALL TAIL LAMPS, BACKUP LIGHTS, AND LICENSE PLATE.